

MICROTEC MT-1500 SPARE PARTS

<u>Part No.</u>	<u>DG No.</u>	<u>Part Name</u>
15-001	1	POWER TRANSFORMER
15-018	2	CONTROL TRANSFORMER
15-012N	3	AMPERE REGULATOR
15-002	4	AMPERE METER
15-003	5	SOLID STATE RELAY
15-027	6	FOOT SWITCH
15-006	7	FAN
15-007	8	FAN GUARD
15-008	9	CONNECTOR FOR FOOT SWITCH
15-009	10	CONNECTOR FOR POWER SWITCH
15-043	11	TIMER RESISTOR
15-011	12	KNOB FOR TIMER
15-019	13	SILICON RECTIFIER
15-020	14	S.C.R. THYRISTOR
15-021	15	SR DIODE RECTIFIER
15-043	16	RESISTOR
15-022N	17	CONDENSER
15-015	18	FUSE HOLDER
15-025	19	TUBE FUSE
15-014	20	EARTH LEACKAGE BREAKER
15-039	21	SUPPORT
15-044	22	P.C.B. SOCKET
15-045	23	P.C.B. SUPPORT
15-046	24	BLACK BOARD
15-047	25	PILOT LAMP
15-048	26	RUN LAMP
15-026	27	KNOB
15-004	28	AUTO SWITCH
15-017	29	TRANSFORMER
15-036N	30	RESISTOR
15-039	31	CARBON RESISTOR
15-037	32	CONDENSER FOR CONTROL
15-029	33	S.R. DIODE RECTIFIER
15-028N	34	TERMINAL STRIP
15-MTF1	35	MICROTEC MT1500 FRONT PANEL
15-MTC1	36	MICROTEC MT1500 OUTER CASE